



ACI QUAT

DIN#02244321

LIQUID DISINFECTANT FOR HARD SURFACES

Didecyl Dimethyl Ammonium Chloride:	0.9%
Alkyl (C ₁₄ 50%, C ₁₂ 40%, C ₁₆ 10%) Dimethyl Benzyl Ammonium Chloride:	2.0%
Octyl decyl Dimethyl Ammonium Chloride:	1.5%
Dioctyl Dimethyl Ammonium Chloride:	0.6%

Acidic cleaner & wide spectrum disinfectant

DESCRIPTION

ACI QUAT is a foaming disinfectant that could be used by circulation or manual application to disinfect non-porous hard environmental surfaces in a food processing plant.

APPLICATION

Remove gross filth and heavy soil deposits. Pre-clean all surfaces prior to sanitation.

To Sanitize: Thoroughly wet surfaces. Dilute 1 part **ACI QUAT** in 100 parts water (10mL **ACI QUAT** /1 Liter of water), This dilution provides 500 ppm of active quaternary ammonium. **ACI QUAT** can be applied with a mop, sponge, or cloth as well as coarse (trigger) spray. Prepare a fresh solution for each use then discard. Apply the solution for 10 minutes (contact time); then rinse with abundant potable water.

PROPERTIES

Appearance: Clear liquid

Odor: Pleasant

pH (0.4% solution): 2.00 ± 1.00

Specific gravity @ 25°C: 1.150 ± 0.050