



# ATO FLOC DADMAC

## DE-INKING POLYMER

### DESCRIPTION:

This product is a high charge cationic, medium molecular weight polymer in liquid form. Its main use is as a coagulant in potable water treatment, where it is used as a filter aid and for removal of colour in low turbidity streams. It is also used as a coagulant in conjunction with other polymers in treating waste water.

### TYPICAL PROPERTIES:

Appearance .....	straw coloured liquid
Viscosity .....	1000 – 4000 cps
Specific Gravity .....	1.03-1.09
Freezing Point in C .....	- 3
pH 1% solution.....	5 – 7
Shelf Life .....	2 years