



ATO QUAT II

SANITIZER AND DEODORANT

DESCRIPTION

ATO QUAT II is a ready to use deodorant and sanitizer. It is engineered to be vaporised in order to sanitize the air in garbage compactors, aeration circuits and production areas. Vaporise with a foager in garbage compactors. To sanitize the air in production areas and in aeration circuits, vaporise 200 ppm by diluting 1 part of **ATO QUAT II** in 32 parts of water (125 ml of **ATO QUAT II** in 4 liters of water)

APPLICATION

To sanitize:

For use on hard non-porous surfaces such as counter tops in food processing establishments. Preclean all surfaces prior to sanitizing. Dilute 1 part of **ATO QUAT II** in 32 parts of water (125 ml of **ATO QUAT II** in 4 liters of water). This dilution gives 200 ppm of active quaternary ammonium chloride. Do not rinse if the concentration is equal or below 200 ppm.

PROPERTIES

Colour: Green liquid

Odour: Apple

pH (as is): 7.00±1.00

Specific gravity @ 25°C: 1.000±0.050

Solubility: Complete

PRECAUTIONS

HARMFUL IF SWALLOWED OR INHALED. DO NOT SWALLOW. DO NOT INHALE AEROSOLS OR VAPORS. MAY IRRITATE EYES OR SKIN. DO NOT GET INTO EYES OR SKIN OR CLOTHING. AVOID CONTAMINATION OF FOOD. WEAR RUBBER GLOVES AND GOGGLES.

INGREDIENTS

Contains: Quaternary ammonium chloride and fragrance.

MADE IN CANADA

FOR FOOD OR INDUSTRIAL ESTABLISHMENTS