



CHLORAT HF

LIQUID ALKALINE CHLORINATED FOAMING CLEANER

DESCRIPTION

Chlorat HF is a special cleaner for food processing establishments uses. **Chlorat HF** was engineered as a chlorinated alkaline cleaner. It is a foaming cleaner.

APPLICATION

GENERAL CLEANING: use at 1-5% (10 ml – 50 ml **Chlorat HF** in 1 liter ; 1.28 – 6.4oz / gal) solutions, let the solution in contact with surfaces for at least 10 minutes then rinse with water.

For food plant use, food contact surfaces are to be rinsed with abundant potable water before re-use. For specific uses, follow Company Representative's instructions and methods of use.

PROPERTIES

Appearance : Clear yellowish liquid

Odeur: Slight chlorine

pH (1% solution): 12.00±0.50

Specific gravity @ 25°C : 1.220 ± 0.010

Solubility: Instant and complete

PRECAUTIONS

Not safe on soft metals. Avoid all contact with skin or eyes. Wear rubber gloves and goggles while handling.

FIRST AID: For SKIN or EYE contact, immediately rinse with abundant water for at least 15 minutes. For EYES, obtain medical attention. If swallowed, DO NOT INDUCE VOMITING, give 3-4 glasses of water or milk, obtain medical care immediately. Garments must be cleaned.