



# CHLORAT NF

## Liquid alkaline chlorinated non-foaming cleaner For Industrial Dishwashers

### DESCRIPTION

**CHLORAT NF** is a special cleaner for automatic dishwashers. **CHLORAT NF** was engineered as a chlorinated alkaline cleaner. It is a non foaming cleaner.

### APPLICATION

**GENERAL CLEANING:** use at 0.5%-2% solutions, circulate for 10-20 minutes at 60°C.

For specific uses, follow Company Representative's instructions and methods of use.

### PROPERTIES

Appearance : Clear yellowish liquid

pH (1% solution): 12.00±0.50

Specific gravity @ 25°C : 1.220 ± 0.010

Available chlorine: (min.) 2.0%

Solubility: Instant and complete