



DE DRAIN

Liquid plumbing cleaner

DESCRIPTION

DE DRAIN is an alkaline liquid plumbing cleaner. **DE DRAIN** dissolves all organic matter, food residues, hair, grease, wood, soap, cloth, etc. that clog drains, plumbing, sink traps, toilet, urinals, sewers, etc. **DE DRAIN** is safe to use on all plumbing composed of iron, copper, brass, glass, and plastic pipes.

APPLICATION

Use as is. Let the product in contact with the organic materials for 10 minutes, then rinse with abundant water.

PROPERTIES

Appearance: Brownish liquid

pH (as is): 14.00 ± 1.00

Specific gravity @ 25°C: 1.030 ± 0.050

INGREDIENTS

Contains: Potassium hydroxide and gluconate.