



EVOLUTION

Neutral foaming degreaser

DESCRIPTION

EVOLUTION is a proprietary blend of surfactants having wetting, penetrating and cleaning properties. It is very effective in removing grease on hard surfaces. The efficacy of **EVOLUTION** may be seen within few minutes after its application.

BENEFITS

Neutral product
Biodegradable
Environmentally friendly
Safe to handle.
Removes grease efficiently
Eliminates harsh and dangerous cleaning chemicals and solvents.

APPLICATION

Use **EVOLUTION** at a concentration of 1 to 5%. Spray **EVOLUTION** on the surfaces to be cleaned. Let it stay for at least 10 to 30 minutes then rinse with water at high pressure.

PROPERTIES

pH (as is): 7.00 ± 0.50
Specific gravity @ 25°C: 1.000 ± 0.050
Solubility: Complete