



# FOR-OVEN

## Heavy-duty foaming degreaser for carbonised organic deposits

### DESCRIPTION

**FOR-OVEN** is a heavy duty degreaser specially formulated to dissolve, solubilise and remove baked-on oil, grease and carbonized matter attached to **Grills, Oven** and **Frying Pans**.

### APPLICATION

**GRILLS:** Pre-heat the surface to a temperature above 80°C. Spray on **FOR-OVEN** as is and give it 5 minutes to penetrate encrusted soils. Scrape-off with scraper and rinse with potable water.

**OVEN:** Dilute **FOR-OVEN** to a concentration of 25-40%, spray on all surfaces, let it react for 5 minutes and rinse off with potable water.

**FRYING PANS:** Remove excess grease with hot water. Add 20% solution of **FOR-OVEN** and let it boil for 5 minutes then rinse with potable water.

### PROPERTIES

Appearance: Colorless liquid

pH (as is): 12.50±1.00