



# ORA

## Heavy-duty foaming degreaser

### DESCRIPTION

**ORA** is a citrus-scented, concentrated liquid cleaner. **ORA** is the product of choice for heavy-duty degreasing and cleaning efficiency. **ORA** is a stable product which can be used safely on all types of surfaces, including vinyl and leather.

### DIRECTIONS FOR USE

**ORA** is a new biotechnology product that replaces the harsh corrosive degreasers found in the market place. **ORA** can be used in cleaning industrial plants and machines as well as household furniture and floors. The concentration will depend on the type of soiling. For heavy-duty cleaning (i.e., grease, oil, floors, etc.,) use at a concentration of 5%. For automotive parts, engines, transmissions and housings, use at a concentration of 10%.

**FOAM APPLICATION:** For optimal results, use **ORA** with high pressure FOAMER. For general cleaning of walls, tables, chairs, etc., use at a concentration of 3%.

### PROPERTIES

Appearance: Clear orange liquid

Odour: Citrus

pH (1% solution):  $9.50 \pm 1.00$

Specific gravity @ 25°C:  $1.010 \pm 0.010$

Solubility: Complete