



OXY CHLOR 12

SANITIZER

SODIUM HYPOCHLORITE

DESCRIPTION

OXY CHLOR 12 is a solution of sodium hypochlorite. **OXY CHLOR 12** is a sanitizer that controls microorganisms such as bacteria, yeast and mold.

APPLICATION

Cleaning: Use **OXY CHLOR 12** at a concentration of 0.2 to 3% in water.

For food plant use, food contact surfaces should be rinsed with abundant potable water before re-use.

Sanitation in food plants: (meat, fish, poultry, dairy and other food plants): use at a concentration of 0.2% maximum (2ml per liter). Do not rinse if concentration is at 200 ppm available chlorine or below.

For fish processing plants: Use to treat influent processing water for microbial control. Product should be fed into incoming water source with appropriate metering equipment and monitoring controls so as not to exceed 3 ppm total chlorine.

PROPERTIES

Appearance: Yellowish liquid

pH (1% solution): alkaline

Available chlorine~ 12%