



## **REACTION 2000**

### **NON-FOAMING LIQUID ALKALINE CLEANER**

#### **DESCRIPTION**

**RÉACTION 2000** is a special cleaner for food processing establishments uses. **RÉACTION 2000** was engineered as a non-foaming, sequestrant - based alkaline cleaner.

#### **APPLICATION**

**GENERAL CLEANING:** use at 0.5%-2% (0.64 – 2.56 oz/gal) solutions, circulate for 10-20 minutes at 60°C (140°F).

For food plant use, food contact surfaces are to be rinsed with abundant potable water before re-use. For specific uses, follow Company Representative's instructions and methods of use.

#### **PROPERTIES**

Appearance : Clear liquid

Odeur: Slight

pH (1% solution): 12.00±0.50

Specific gravity @ 25°C : 1.320 ± 0.010

Solubility: Instant and complete

#### **INGREDIENTS**

Contains : Potassium hydroxide, sequestering agents.