



RINSY

Reduces surface tension For Industrial Dishwashers

DESCRIPTION

RINSY is a rinse additive for automatic dishwashers. **RINSY** is a combination of liquid surfactants that reduce the surface tension of water, resulting in even and rapid water sheeting. With **RINSY** glasses, utensils, and dishes will be spotless.

APPLICATION

Rinse additive: **RINSY** can be added automatically to rinse water. Only 50-300ppm is sufficient to reduce the surface tension of water.

PROPERTIES

Appearance: Blue liquid

Odor: Bland

pH (as is): 7.00 ± 1.00

Specific gravity @ 25°C: 1.000 ± 0.050