



SANI FOAM

ALKALINE CHLORINATED FOAMING CLEANER AND SANITIZER

DESCRIPTION

SANI FOAM is a special cleaner and sanitizer for food processing establishments uses. **SANI FOAM** was engineered as a chlorinated alkaline cleaner. It is a foaming cleaner.

APPLICATION

GENERAL CLEANING: use at 1-5% (10 ml – 50 ml **SANI FOAM** in 1 liter ; 1.28 – 6.4oz / gal) solutions, let the solution in contact with surfaces for at least 10 minutes then rinse with water.

SANITATION: use at a concentration of 1.5%. this concentration will provide 300 available chlorine. let the solution in contact with surfaces for at least 10 minutes then rinse with water.

PROPERTIES

Appearance : Clear yellowish liquid

Odeur: Slight chlorine

pH (1% solution): 12.00 ± 0.50

Specific gravity @ 25°C : 1.220 ± 0.010

Solubility: Instant and complete