



SOLID

Caustic free biodegradable cleaner

Unique to  atomes

DESCRIPTION

SOLID is a powdered cleaner formulated specifically for breweries. **SOLID** is used to clean surfaces in contact with food, reservoirs, C.I.P. evaporators, fillers, aseptic equipment and pasteurisers. **SOLID** can be used also in dairies, wineries, food-processing, beverage and meat processing and packaging plants.

DIRECTIONS FOR USE

Use **SOLID** at a concentration of 1 to 5%. Dilute 10 to 50 g **SOLID** in 1 liter water.

Let it circulate for at least 10 to 30 minutes then rinse with abundant potable water.

PROPERTIES

Appearance: White powder

Odour: Mild

pH (1% sol.): 10.00 ± 0.50

Specific gravity @ 25°C: 1.350 ± 0.050

Solubility: Complete